Fluke 560 Series **Infrared Thermometers**



With a straight-forward user interface and softkey menus, the Fluke 566 and 568 make even $complex \ \ measurements \ easy. \ With \ just \ a \ few$ pushes of a button you can easily adjust emissivity, start data logging, or turn on and off alarms. With a rugged, easy-to-use design, the Fluke 566 and 568 can stand up to tough industrial, electrical, and mechanical environments.

Fluke 566 and 568 IR and Contact

Measure up to 800 °C (1470 °F)

Thermometers

- Easily access advanced features with the softkey buttons and graphical display
- Measure smaller objects from further away
- Compatibility with most type K thermocouples
- Confidently measure more surfaces, with adjustable emissivity and built-in materials table
- Log and download measurements for reporting (568)
- Two levels of backlight
- Audible and visual alarms alert you to measurements outside of set limits
- Min/Max/Avg/Dif functions
- Includes KTC bead probe
- 1 % measurement accuracy
- Versatile interface with six languages

Specifications

 $C \in$

Models	Fluke 561	Fluke 566	Fluke 568
Infrared temperature range	-40 °C to 535 °C (-40 °F to 1022 °F)	-40 °C to 650 °C (-40 °F to 1200 °F)	-40 °C to 800 °C (-40 °F to 1470 °F)
Accuracy	greater of ± 1 % or ± 1 °C (2 °F)		
Distance to Spot (D:S)	12:1	30:1	50:1
Sighting	Laser point		
Typical distance to target	Up to 2.5 m (7 ft)	Up to 4.5 m (15 ft)	Up to 7.5 m (25 ft)
Probe type	Thermocouple K		
Contact temperature range	-40 °C to 550 °C (-40 °F to 1022 °F)	-270 °C to 1372 °C (-454 °F to 2501 °F)	
Number of on-board memory locations	-	20	99
PC download and software	_	-	Yes, with FlukeView® Forms
Soft-key feature menu navigaton	-	Yes	
Min/Max/Avg/Dif	Min/Max/Dif	Min/Max/Avg/Dif	
English, French, Chinese, Spanish, Portuguese, German user interface	-	Yes	
Material type adjustment (emissivity)	Hi/Med/Lo	Material table or 0.1 to 1.00 by 0.01	
Two levels of backlight	-	Yes	
High and low alarms	-	High and low alarms	
Hands-free logging	_	-	Yes
Battery	2 AA		
Included case	Hard case (except 561/R and 561/P)	Hard case	
Warranty	Two-year		

Ordering information

Included accessories	Models	
USB cable, FlukeView® Forms software, thermocouple type K bead probe, carrying case, two AA batteries, users manual, quickstart guide.	FLUKE-568	Infrared Thermometer
Thermocouple type K bead probe, carrying case, two AA batteries, users manual and quickstart guide.	FLUKE-566	Infrared Thermometer
Thermocouple type K pipe probe, carrying case, two AA batteries, users manual.	FLUKE-561	Infrared Thermometer
Q V hattery instruction sheet	FI IIKF_61	Infrared Thermometer





B.L.W. Visser B.V.

Cromhoffsbleekweg 146 7513 EW ENSCHEDE Nederland

Tel: +31 (0)53 4319661 E-mail: info@blwvisser.nl Internet: www.blwvisser.nl

Specialty models

Fluke 561 Infrared and **Contact Thermometer**

The Fluke 561 combines the temperature measurement functions that professionals need for most HVAC and industrial jobs, all in one tool.

- · Pipe probe for superheat and sub-cooling and other contact and ambient measurements
- Min/Max/Dif functions help you quickly identify problems
- Scan large areas or small objects quickly and efficiently

Fluke 61 Infrared **Thermometers**

- · Easy to use one button operation
- · Easy targeting with bright laser
- Shock-absorbing molding increases ruggedness
- Two-year conditional warranty
- Temperature measurement range up to 275 °C (525 °F)
- 8:1 optics
- Accurate to within ± 2 % of reading or 2 °C, whichever is greater
- · Recommended optional carrying case, C25

Recommended accessories



Pipe Clamp Probe





Industrial Surface Temperature Probe See page 60





80PK-8 Pipe Clamp Probe See page 61

80PK-18 Pipe Clamp Probe Kit See page 61





80PK-22 SureGrip™ Immersion Probe *See page 60*

C1600 Gear Tool Box See page 56

Check price and availability at www.fluke.com/wtb